

BeanGateway® 2.4GHz

With 3G / 4G / LTE / Connectivity

For 2.4GHz Sensors



2.4GHz



Contents

- 1. TECHNICAL SUPPORT..... 3**
- 2. VISUAL SYMBOLS DEFINITION..... 3**
- 3. ACRONYMS AND ABBREVIATIONS..... 4**
- 4. QUICK PRODUCT DESCRIPTION 4**
 - 4.1-UNBOX YOUR BEANGATEWAY® 2.4GHz 4G 4
 - 4.2-ACCESSORIES DESCRIPTION 5
- 5. INSTALLATION 6**
- 6.DEFAULT SETTINGS..... 10**
- 7.HOW TO SETUP A REMOTE ACCESS IN 4 STEPS (EXAMPLE OF IP FORWARDING METHOD) 13**
 - 7.1-STEP 1: AT YOUR OFFICE, CONFIGURE YOUR FIREWALL FOR REMOTE ACCESS 14
 - 7.2-STEP 2: AT YOUR OFFICE, CONFIGURE IP FORWARDING RULES 14
 - 7.2.1-Example with ADSL MODEM (NAT ROUTER Configuration) 14
 - 7.2.2-Example of 4G Router (SIM CARD Provider Olivia wireless) 17
 - 7.2.2.1-System Architecture 17
 - 7.3-STEP 3: AT YOUR OFFICE, CONFIGURE THE PORT NUMBER ON YOUR BEANSCAPE® 24
 - 7.4-STEP 4 : BEANGATEWAY® CONFIGURATION ON THE MONITORING SITE 24
 - 7.4.1-Sim card configuration 24
 - 7.4.2-Make sure the DHCP is enabled on your LTE router 26
 - 7.4.3-BeanGateway® 2.4GHz configuration with Public IP of your Office PC 27
- 8.WHERE TO FIND MORE TECHNICAL INFORMATION 31**

List of Figures

DISCLAIMER

The information contained in this document is the proprietary information of BeanAir®.

The contents are confidential and any disclosure to persons other than the officers, employees, agents or subcontractors of the owner or licensee of this document, without the prior written consent of BeanAir® GmbH, is strictly prohibited.

BeanAir® makes every effort to ensure the quality of the information it makes available. Notwithstanding the foregoing, BeanAir® does not make any warranty as to the information contained herein, and does not accept any liability for any injury, loss or damage of any kind incurred by use of or reliance upon the information.

BeanAir® disclaims any and all responsibility for the application of the devices characterized in this document, and notes that the application of the device must comply with the safety standards of the applicable country, and where applicable, with the relevant wiring rules.

BeanAir® reserves the right to make modifications, additions and deletions to this document due to typographical errors, inaccurate information, or improvements to programs and/or equipment at any time and without notice.

Such changes will, nevertheless be incorporated into new editions of this document. Copyright: Transmittal, reproduction, dissemination and/or editing of this document as well as utilization of its contents and communication thereof to others without express authorization are prohibited. Offenders will be held liable for payment of damages. All rights are reserved.

Copyright © BeanAir GmbH 2022

1. TECHNICAL SUPPORT

For general contact, technical support, to report documentation errors and to order manuals, contact BeanAir® Technical Support Center (BTSC) at:

tech-support@beanair.com




For detailed information about where you can buy the BeanAir® equipment/software or for recommendations on accessories and components visit:

www.beanair.com

To register for product news and announcements or for product questions contact BeanAir's Technical Support Center (BTSC).

Our aim is to make this user manual as helpful as possible. Please keep us informed of your comments and suggestions for improvements. BeanAir® appreciates feedback from

2. VISUAL SYMBOLS DEFINITION

Symbols	Definition
	Caution or Warning – Alerts the user with important information about BeanAir® wireless IOT Sensors. if this information is not followed, the equipment /software may fail or malfunction
	Danger – This information MUST be followed if not you may damage the equipment permanently or bodily injury may occur.
	Tip or Information – Provides advice and suggestions that may be useful when installing BeanAir Wireless IOT Sensors.

3. ACRONYMS AND ABBREVIATIONS

AES	Advanced Encryption Standard
CCA	Clear Channel Assessment
CSMA/CA	Carrier Sense Multiple Access/Collision Avoidance
GTS	Guaranteed Time-Slot
kSps	Kilo samples per second
LDCDA	Low duty cycle data acquisition
LLC	Logical Link Control
LQI	Link quality indicator
MAC	Media Access Control
PER	Packet error rate
POE	Power Over Ethernet
RF	Radio Frequency
SD	Secure Digital
UPS	Uninterruptible power supply
USB OTG	USB On The Go
WDAQ	Wireless DAQ
WSN	Wireless Sensor Networks

4. QUICK PRODUCT DESCRIPTION

4.1 UNBOX YOUR BEANGATEWAY® 2.4GHZ 4G

Open your BeanGateway® Box
 The 2.4GHz 4G Gateway is available in two versions:



• BGTW-4G-MPWR-OUT, Mains Power supply



• BGTW-4G-SOLAR-OUT, Solar Power Supply


It is provided with a 4G antenna, WiFi antenna, external cables for both WiFi & 4G/LTE antennas and a power supply plug (only available with the mains power version).

4.2 ACCESSORIES DESCRIPTION

In addition to the BeanGateway® you will find inside the packet a list of accessories:

- 4G Antenna
- WiFi Antenna
- External cable for Wifi antenna
- External cable for 4G/LTE antenna
- Power supply plug (only available with the mains power version)

4.2 ACCESSORIES DESCRIPTION




For more info on the accessories and its specification please refer to the user manual

5. INSTALLATION


1 : Please follow the following wiring code instructions to correctly build your own AC Power supply

• **MAINS POWER SUPPLY (REF: BGTW-4G-MPWR-OUT)**

The previous hardware version comes with a Female Socket and a Male Plug



• SOLAR POWER SUPPLY (REF: BGTW-4G-SOLAR-OUT)




DC Power:

The solar power controller can work between 13VDC to 20VDC, user can use an AC/DC power adapter in this voltage rating.


i If the DC Voltage is less than 13VDC, the provided voltage will not be enough to power the Solar Power Manager

2: Use the provided antennas cables and power supply cable to connect to the appropriate connectors as shown below in the figure.




3. Open the box enclosure and use the Ethernet cable to connect your Laptop to the router in order to configure the IoT Gateway and get it ready for remote monitoring, as well to insert SIM card. Use a screwdriver to remove the black lid and properly insert the SIM card.


SIM CARD INSERTION



4. Don't forget to turn On the switch mode box by pushing the ON/OFF push button at the top left corner, in order to charge the Lead-Acid Battery and get the gateway ready for configuration.



BGTW-4G-MPWR-OUT, MAINS POWER SUPPLY



BGTW-4G-SOLAR-OUT, SOLAR POWER SUP-

Switch ON/OFF for Load
[BeanGateway® + 4G Router]

Rj45 connector on the
BeanGateway board

Slide switch with ON/OFF
positions to turn on/off
separately the
BeanGateway®

Backup Lead-Acid
Battery 14AH

To Reset LAN Settings
on your BeanGateway®
press and hold this
button for 10s


BeanGateway®
MAC address

Switch ON/OFF
for Battery


Teltonika 4G router
connected to
the BeanGateway®

Solar Power controller


Router 4G antennas



4. Use an ethernet cable to connect the router inside the IOT Gateway® to your laptop.




• Plug the power adapter to your 4G Router, then use an ethernet cable and plug it into the LAN Ethernet port of your Configuration PC.



6. DEFAULT SETTINGS

THE DEFAULT 4G GATEWAY® IP ADDRESS IS 192.168.1.1

1. Assign a static IP address to your PC within the same subnetwork as your BeanGateway®
 - In the search bar tap change ethernet settings, then click on open



- Click on change Adapter settings

Ethernet




Related settings

[Change adapter options](#)


[Change advanced sharing options](#)

- Right click on the Ethernet device with is connected to your IOT Gateway,choose Propertes




- Double click on Internet Protocol Version4 (TCP/IPv4)

This connection uses the following items:




- Enter the following settings:
 - Enter any ip in the form of 192.168.1.XXX where XXX is a number from 2 to 254 (except 243 which is the router IP address).
 - Enter 255.255.255.0 for your subnet mask
 - The default 4G gateway must come with the same IP address that your 4G Router 192.168.1.243
 - Finally enter primary DNS server IP , the same than your 4G Router IP 192.168.1.243
 - Click on OK validate your configuration



- Once your PC and IOT Gaetway® are connected to the same network, you can easily have access to the router.

7. HOW TO SETUP A REMOTE ACCESS IN 4 STEPS (EXAMPLE OF IP FORWARDING METHOD)



Before to start to configure your remote access, make sure your Office router/ADSL Box should come with Fixed Public IP address to avoid losing the BeanGateway® whenever it reboots for any reason.



How to get a fixed public IP:


- If you are using an ADSL Router at your office: you can ask to your ADSL Router provider to allocate you a fixed public IP
- You can purchase a Data SIM card with fixed public IP from your ISP (Example: Olivia Wireless)
 - If you are using a standard SIM card, some PORTS can be blocked by the ISP.



It's not mandatory to use a SIM card with fixed public IP on the monitoring site.

7.1 STEP 1: AT YOUR OFFICE, CONFIGURE YOUR FIREWALL FOR REMOTE ACCESS


You have to enable Routing and Remote Access option for both Private and Public networks, communication through the firewall.



7.2 STEP 2: AT YOUR OFFICE, CONFIGURE IP FORWARDING RULES

7.2.1 Example with ADSL MODEM (NAT ROUTER Configuration)

- 1 From your Office PC, search for your Public IP address (ex: search for MyIP on Google).





Make sure that no antivirus/firewall is blocking the network activity between the BeanGateway® and the BeanScope® software.

2• Setup a Port Forwarding configuration on your Router (each router brand has its own configuration interface).

Example 1: GlobalNet ADSL Router Webserver configuration (North Africa)

The screenshot shows the GlobalNet ADSL Router Webserver configuration interface. The top navigation bar includes the GlobalNet logo and icons for Device Info, Basic Setup, and Advanced Setup. The left sidebar contains a menu with options: Quick Setup, WAN Setup, NAT, Virtual Servers (highlighted), Port Triggering, DMZ Host, IP Address Map, ALG/Pass-Through, LAN, Wireless, Parental Control, and Home Networking.



The main content area is titled "NAT -- Virtual Servers" and contains the following configuration options:

- Select the service name, and enter the server IP address and click "Apply/Save" to forward IP packets for the same value as "Internal Port Start".
- Remaining number of entries that can be configured: 26
- Choose All Interface
- Choose One Interface
- Use Interface:
- Service Name:
 - Select a Service:
 - Custom Service:
- Server IP Address:
- Enable NAT Loopback

At the bottom, there is a table for port forwarding configuration:

External Port Start	External Port End	Protocol	Internal Port Start	Internal Port End
5313	5313	TCP/UDP	5313	5313

Example 2: Fritze Box (Germany)



Please be aware if the public IP Address of your ADSL Box is not fixed, you will lose the connection between the BeanGateway® and your Monitoring PC (at the office), whenever the router reboots. If you are not sure to have a fixed public IP, we suggest you use a 4G Router and a SIM Card with a fixed public IP.

7.2.2 Example of 4G Router (SIM CARD Provider Olivia wireless)


i if you have a 4G router with a SIM card at your office, make sure that the SIM card comes with a Fixed Public IP address and your ISP provider doesn't restrict any port numbers.

In this example we will work with Olivia Wireless SIM card which comes with a Fixed public IP address.

7.2.2.1 System Architecture


Olivia is using a Public Gateway in its system architecture, in order to allow users on the internet to reach the SIM directly.

The Public Gateway is simply a port forward service that's why you have to create a port forwarding rules on both SIM Card platform and also on your office router.



Please follow these steps to correctly configure the system.

- Step 1: Verify that Public IP routes service is enabled on your SIM card interface.
 - We assume that you have already purchased the Fixed public IP service when you set up the payment method.
- To verify that the Fixed Public IP address service is enabled, please login to your SIM Card platform



Olivia

Login


Enter your email address and password to login.

Email Address

Password (forgot?)

- Then go to the tab SIM Cards.

Olivia



Register SIM card

Registered SIM Cards

Export

SIM Barcode	Device Name	SIM State	APN	Rate plan	Activation Date	Data Used
891030000001886354	Test_SIM_CARD	Active	rlh	Selfservice SIM	03/06/2022	150MB

- You should see “Public IP Route” noted under “Deployed Network Service” on the SIM cards details page.

Expiration Date
03/06/2023

Deployed Network Service
Public IP Route

- If it's not the case you have to enable it before proceeding.
- Step 2: Setup Port Forwarding on the Public IP Gateway (SIM Card)
 - Navigate to “SIM card” and click on the SIM barcode

Olivia

- Dashboard
- SIM Cards**
- Support
- Order SIM cards
- My Company
- Help

Register SIM card

Registered SIM Cards

search by keyword search

Export

SIM Barcode	Device Name	SIM State
891030000001886354	Test_SIM-CARD	Active

- Then click on ADD Public IP Route

Top-ups

Order ID
No top-ups available

A Add Public IP Port Route

Inbound access via fixed IP

- Give your route a recognizable name, Enter the port you would like to reach on the SIM/ Router then select the protocol (usually TCP) and click 'Submit'.
- Create the PORT ID of your SIM card (avoid ports 22, 80 and 443)

Add Public IP Port Route

Add Route

Route Name *

Port SIM Side *

Transport layer *

Submit

- A random port on the gateway will now be locked to be used with your SIM card

Routes Name	SIM IP	Port SIM Side	Public IP:Port	Delete
Berlin Site	10.0.17.15	5320	18.158.125.169-41988	



IMPORTANT :

- The PORT ID of your SIM card will be used to create the IP Forwarding rules on your LTE Router running at the office.
- Note the Public IP and the PORT number, it will be used during your BeanGateway® configuration on your monitoring site.

• Step 3: Install the SIM Card on the router and Configure the Mobile Network


In this example we are using Teltonika Router RUT240, but the steps are similar for different types of routers.

Insert the SIM Card into your Router then use the corresponding User Name and Password to log in.

Then Navigate to Network --> Mobile, then Enter the following configuration

- APN: --custom--
- Custom APN: rh

And Keep all the other settings on default then click on save.



- Step 4: Install the SIM Card on the router and Configure the Mobile Network
 - Login to your router, then navigate to Network --> Firewall --> Port Forward

The screenshot shows the Teltonika web interface. At the top, there are navigation tabs: Status, Network, Services, and System. The 'Network' tab is selected, and a dropdown menu is open, showing options like Mobile, WAN, LAN, VLAN, Wireless, **Firewall**, Routing, and Load Balancing. Below the navigation, there are sub-tabs for General Settings, Port Forwarding, Custom Rules, and DDOS Prevention. The main heading is 'Firewall - Port Forwarding'. A brief description states: 'Port forwarding allows remote computers on the Internet to access a specific computer or service within the private network.' Below this is a table titled 'Port Forwarding Rules' with columns: Name, Protocol, Source, Via, and Destination. The first row shows: 'Enable SSH WAN PASSTHROUGH', 'TCP', 'From any host', 'To any router IP at port', and 'Forward to IF'.

Scroll down to New Port Forward Rule and set the following

- Name: Any recognizable name
- Protocol: TCP+UDP
- External port (s): SIM Card PORT ID in our case 5320 (avoid ports 22, 80 and 443)
- Internal IP: Select the IP of your PC
- Internal port (s): Any port on which you want to access (Port used on BeanScape software) 5313

NAME	EXTERNAL PORT	INTERNAL IP ADDRESS	INTERNAL PORT
<input type="text" value="Forward"/>	<input type="text" value="5320"/>	<input type="text" value="192.168.1.31 (00:23:24:73:87:87)"/>	<input type="text" value="5313"/>



Make sure that the port forwarding rule is configured from WAN: External Port (or Source Zone) to LAN: Internal Port.

Firewall - Port Forwards - Forward

This page allows you to change advanced properties of the port forwarding entry. Although, in most cases there is no need to modify those settings.

Enable

Name

Protocol

Source zone

- gre: gre tunnel:
- hotspot:
- l2tp: l2tp:
- lan: lan:
- pptp: pptp:

- sstp:
- vpn: openvpn:
- wan: wan: ppp: tun: (empty) wan2:

Source MAC address

Source IP address

Source port

- l2tp: l2tp:
- lan: lan:
- pptp: pptp:
- sstp:
- vpn: openvpn:
- wan: wan: ppp: tun: (empty) wan2:

Internal IP address

Internal port

Enable NAT loopback


Extra arguments

Back to Overview

Save

7.3 STEP 3: AT YOUR OFFICE, CONFIGURE THE PORT NUMBER ON YOUR BEANSCAPE®

On your office PC don't forget to put the BeanScape TCP port number the same as the internal Port TCP number chosen in the router port forwarding configuration rule.



If you change the default TCP port on BeanScape software to another port number different than 5313, you have to restart the server to establish the connection with the monitoring site.

7.4 STEP 4: BEANGATEWAY® CONFIGURATION ON THE MONITORING SITE


Now that you have your Public Fixed IP of your BeanScape® software running at your office. You can start to configure your BeanGateway® and LTE Router running on the monitoring site.

7.4.1 Sim card configuration

Use your browser on your PC and log in to the router using the following settings:

- IP address: 192.168.1.243 (tap it in google search bar)
- Username: admin | password: Beanair2020!

To configure your 4G/LTE Router go on Network then Click on Mobile



- Now configure your mobile settings as follow

General Network Operators Mobile Data Limit

Mobile Configuration

Mobile Configuration

SIM 1

Connection type: QMI

Mode: NAT

Passthrough and Bridge modes are disabled when NAT is enabled

Auto APN: Connection will be established automatically

PIN number: 0000

PUK code:

Dialing number: *99#

MTU: 1500

Service mode: Automatic

Deny data roaming:

Mobile Data On Demand

Enable:

No data timeout (sec): 10

Force LTE network

Enable:

Reregister:

Interval (sec): 300

Save

Choose QMI connection type because PPP is slower than QMI. **QMI option is highly recommended.**

Check Auto APN and the connection will be established automatically. **Access Point Name (APN):** is a configurable network identifier used by a mobile device when connecting to a GSM carrier

Enter the right PIN number and PUK code of your SIM card

Used this field only if the SIM card's PIN number was used

Choose 1500

Choose Automatic as a service mode

Uncheck Deny data roaming option





You can get the APN ID from your telecom operator provider



If an invalid PIN number was entered (i.e. the entered PIN does not match the one that was used to protect the SIM card), your SIM card will get blocked. To avoid such mishaps, it is highly advised to use an unprotected SIM. If you happen to insert a protected SIM and the PIN number is incorrect, your card won't get blocked immediately, although after a couple of reboots OR configuration saves it will.

7.4.2 Make sure the DHCP is enabled on your LTE router

LAN IP address should be 192.168.1.243 by default and if this is not the case for whatever reason ,you will need to set it back to 192.168.1.243 in the configuration panel you can find in the overview page




7.4.3 BeanGateway® 2.4GHz configuration with Public IP of your Office PC

Now that your LTE Router is configured with your SIM card, it's time to configure correctly your BeanGateway® 2.4GHz


Right after connecting your BeanGateway® 2.4GHz to your PC via the LAN cable,

1. Right click on your BeanScape® software icon then click on [Open](#)




2. Switch to Expert view

Beanscape 2.4GHz




3. Navigate to Tools --> BeanGateway Ethernet/LAN config


Beanscape 2.4GHz




- 4. Select your LAN card IP Address (192.168.1.244), then click on Localize



- 5. After Localization process, select your 4G BeanGateway® MAC ID



- 6. Check DHCP option to assign an automatic IP address to your BeanGateway®, then click on validate




7. On BeanScape® frame:

• Case 1 - If you are using a ADSL Router at your office

Make sure to allocate the Public IP of the PC Hosting Beanscape software (you will get your Public IP from step 2)

- In this case the Public IP is 188.106.107.201



• Case 2 - If you are using a LTE Router with a Data SIM CARD (example of Olivia Wireless SIM CARD)

To forward data communication of your BeanGateway® to your Office PC, enter the Fixed Public IP address which was created on the SIM Card before and its corresponding TCP Port number.

Example of IP forwarding Rules created on the Router

Routes Name	SIM IP	Port SIM Side	Public IP:Port	Delete
Berlin Site	10.0.17.15	5320	18.158.125.169:41988	

The screenshot displays the 'BeanGateway Ethernet/LAN configuration' window. Key settings include:

- Localize BeanGateway:** 192.168.1.31 LAN Card, Localize button.
- Configuration:** DHCP Enabled (checked).
- BeanGateway TCP/IP:** IP address: 192.168.1.____, Sub network mask: 255.255.255.0__, Default gateway IP: 192.168.1.___1__.
- DNS:** DNS Enabled (unchecked), DNS IP AUTO (unchecked).
- BeanScape:** Port: 41988, IP address: 18.158.125.169, Domain name: _____.
- Keep Alive App Config:** enabled (unchecked), KAA timeout (ms): 15000, KAA interval (ms): 4000, Max. retry nbr: 7.
- Configuration via Ethernet (UDP):** enabled (checked), Udp port: 53130.
- Public IP:Port:** 18.158.125.169:41988.



Make sure to use the Fixed Public IP address and the TCP Port number which are created on the SIM Card rule.

Do Not use Google to search for your Public IP address, it will give you the IP address of the roaming ISP provider and the remote configuration will not work.

8. WHERE TO FIND MORE TECHNICAL INFORMATION ?

For more technical literature, please visit our White Paper Page:

Please refer to the BeanDevice® 2.4GHz EcoSensors user manual section for more information
<https://www.wireless-iot.beanair.com/files/UM-RF-03-ENG-EcoSensor-Wireless-Sensors-for-En->

For detailed information on the available Data Acquisition mode ,please refer to our technical note
<http://www.wireless-iot.beanair.com/files/TN-RF-008-Data-acquisition-modes-available-on-the-BeanDevice.pdf>

Facing technical problems ?
 Contact our technical support team at :
tech-support@beanair.com





BeanAir Germany
Wolfener Straße 32-34
12681 Berlin - Germany



Visit us:
www.beanair.com



Email:
info@beanair.com



Office line:
+49 (0) 30 98366680